Declassified in Part - Sanitized Copy Approved for Spurity Office Memorandum	Relea INFOR	use 2012/09/13 Mation UNITED	S: CIA-RDP78 STATES	3-03535A0018000	3 ( > ) )10026-2
TO : Chief, Engineering Division	1		DATE:	4 January 195	52
FROM:		•		,	STAT

1. An interview was had on 3 January with Messrs. Turner and Jenson

SUBJECT: D.F. Equipment - F.C.C. and F.B.I.

of the F.C.C.

- 2. The long range direction finder used by the F.C.C. is one built to their specifications using a manually rotated Adcock antenna mounted on top of a wooden shelter. The indication is by aural null, the receivers used: SX-28. SP-600-JX. and 51-J.
- 3. Much dependence is placed on mobile units, mounted in automobiles. These are the Finch model F-115-A, and employ a rotatable loop mounted on the vehicle roof.
- 4. The so-called "Snifter" is a small suit-case type aperiodic portable receiver manufactured by Fada. It is of low sensitivity, and indicates relative field strength on a meter. It indicates signals from 200 kc to 60 mc.
- 5. The Series K aperiodic receiver, manufactured by the Kann Manufacturing Company of Baltimore, Md., is AC powered and can be used for unattended monitoring of a near-by transmitter. It includes a relay which will turn on a recorder during periods in which a signal is received.
- 6. The F.C.C. Research Laboratory, at Laurel, Md., is currently developing a superheterodyne receiver designed to be worn on a waist-belt. This receiver will have plug-in front ends for various frequency ranges.
- 7. Mr. Conrad, of the F.B.I., stated that the only small units used by the Bureau were listening sets manufactured by Schmidt, of Connecticut. These are slightly larger than a hearing aid and have accessories for indicating relative field strength and for detecting the presence of microphones in rooms. He was of the opinion that these sets were used by some units of the Agency.

DOCUMENT NO. 5

NO CHANGE IN CLASS. []

If DECLASSIFIED

CLASS. CHANGED TO: TS S

NEXT REMIEW DATE:

AUTH: HR 70.2

DATE: 12 REVIEWER: 037169

STAT