STATINTL	Approved For Release 2007/07/25 : CIA-RDP78B04747A001000060034-4	
(ソ		
(2)) (
(3)		
	Stellar Comparátor	
	Statta: Combarator	
STATINTL		
STATINTL	and I visited Lab in	STATINTL
STATINTL	to get some background information on the use	STATINTL
	of a laser as the measuring device in the stellar comparator. We talked to	STATINTL
STATINTL	Senior Staff Scientist; Assistant to the	
STATINTL	Director; and customer relations.	
STATINTL	reviewed some of the fundamentals of the	
	Spectra Physics lasers with particular reference to the resonance features important to the interferometry tech-	
	niques used in the measuring devices. Interferometry is	
	sensitive business and needs precise adjustment to work.	
STATINTL	pointed out that a laser will not only	
	resonate at its principal mode at a precise wavelength,	
	but will also resonate at sidebands which have a very slightly different wavelength. The sidebands in effect	
	produce noise on the interference bands and should be	
	suppressed if possible. This can often be accomplished by reducing the intensity of the laser beam. This	
	produces insufficient stimulation to excite the sidebands.	
	The use of the short 13 inch laser was proper since it had fewer sidebands.	
CTATINITI		
STATINTL	suggested four things which could be done as practical improvements in the use of the laser:	
	1. Carefully adjust the hemispherical resonator	
,	on the laser to obtain full spatial coherence	
	across the laser beam.	
	2. Reduce the intensity of the beam to the mini-	
	mum usable value in an attempt to suppress the side bands.	
	3. Use a high pass filter in the detecting circuit to eliminate the low frequency fluctua-	
	tions introduced by the power supply.	
	4. Move the laser back and forth along the light	
	path to insure that 10 inch measuring travel was	
	centered in the most sensitive portion of the beam.	
STATINTL	The people at were reassuring in that they	
	considered the concepts in the use of the laser as a meas-	
	uring tool to be sound. Of course they could give no op- inion on the detail execution.	7
Declass R	eview by NIMA / DoD	STATINTL
	1	

Approved For Release 2007/07/25 : CIA-RDP78B04747A001000060034-4

STATINTL

STATINTL (1) (2) (3)	Approved For Release 2007/07/25: CIA-RDP78B04747A001000060034-4 (Separate Copy) (The April 24, 1964 Electroluminescence	TATINTL
STATINTL		
STATINTL	manufactures plastic panels, laminates and coatings for the Aerospace industry. Their home office	STATINTL
	Their panels are made by depositing a green phosphor on an opaque plastic base and then covering that with a tramsparent plastic material. Different colors are obtained by coloring the transparent plastic overlay. Electrodes are attached to apply a voltage across the This must be an AC voltage as the phosphor. It is not excited by a DC field. They use 115 volta, 400 cycles AC as their standard. Their panels are all special design, design, made to order shapes. Cost varies but is in the range of \$50 per square foot. The principal application is for instrument panels and other displays.	
	At present their largest panel is 3 ft. by 2 ft, limited by manufacturing equipment. The minimum wall thickness is 3/16 inch. They make only flat panels. They can make contoured panels but such panels are expensive, difficult to manufacture and the rejection rate is high.	
STATINTL	Brightness under normal conditions starts out at 7 ft. Lamberts and decays as some function of e to 2 ft. Lamberts in 1000 hrs. In 2000 hours it reaches 1½ ft. Lamberts and continues to approach some minimum value asymtotically. Brightness can be increased by increasing frequency and voltage. At 208 volts and 800 cps, the brightness will increase to approximately 20 ft. Lamberts, however life is considerably reduced under these conditions. said that had made an experimental panel which achieved a brightness of 200 ft. L. It was however a complicated set up and the panel had to be water cooled. Panel life was probably very short.	STATINTL
STATINTL	I told that my interest was the possible application of E.L. panels as a light source for photo viewing and I wanted about 1000 ft. L. He said their pamels were not bright enough. They had looked at medical X-ray negatives laid on the panels and it was a little difficult to observe details readily.	STATINTL

Approved For Release 2007/07/25 : CIA-RDP78B04747A001000060034-4 March 10, 1964 Hevelop Processing Techniques (Proposal) STATINTL had a number of topics STATINTL such as the Chip to review with STATINTL Processor proposal, the Enhancer, the ABD-4 Dryer, the HTA/5 investigative program, and the HTA/6. This is a full weeks agenda. I attended the discusssions on Tues Mar. 10 on the HTA/5 Investigative Program and the discussions with STATINTL Chip Film Processor. Extensive discussion of the proposed investigative program covered a wide range of aspects of the work. proposes to set up a separate group reporting to STATINTL a Research Coordinator who reports directly to the Director of Engineering. They will put a portable clean room in an enclosed area at the North end of their plant. agreed with the need for strict STATINTL security of the area and the control of visitors. Some examples of the program tasks were discussed such as the need for some basic facts bearing on the requirement for solution filtering and the need for maintaining a clean room condition. This is amenable to investigation and will be part of the program. described his proposed chip film STATINTL He is also full of ideas for the applicaprocessor. tion of his air and liquid bearings: He mentioned a straight through processor in which the film enters horizontally at the middle of the developer tank, passes through fix and wash and exits from the middle of the wash tank with no mechanical barriers. He also mentioned applying his ari air bearings to reductions in size of coating alleys. They can't touch the coated emulsion until it dries, so his air bearing permits them to loop the film around without touching it. He is alse investigating a new pressure boost processing technique. has done considerable development of his a STATINTL concept of a chip film system. He is aiming at the commercial amateur market, but much of it is directly STATINTL applicable the chip film requirements in your shop.

	Approved For Release 2007/07/25 : CIA-RDP78B04747A001000060034-4	
(3)	Ammil 1 1006	
STATINTL STATINTL	Digital Readout Comparator	STATINTL
	The first system was shipped to on Jan. 17, 64. According to their shipper, they shipped:	STATINTL
	l ea. Control Panel 2 ea. Counters 3 Manuals Model 2825 A Serial #1 Model 2826 A Serial #1 and Model 2827 A Serial #1 Model 2827 A Serial #1 Model 2827 A Serial #1	2
STATINTL STATINTL	stressed that the Model A counter is for the Cptosyn reading head which is what is using. He had had no word from regarding any	STATINTL
STATINTL	differences in wiring or other problems with the counters. Storie will call to see if there is any-thing he should know about.	
STATINTL	The second system was shipped to Franconia on Feb. 25 and according to the shipper it contained:	
	1 ea. Control Panel Model 2825 A Ser. #2 2 ea. Counters Model 2826 B Ser. #1 and 2 1 ea. Synchronizer Model 2827 A Ser. #2 22 Cables 3 Manuals	
STATINTL	checked with the engineer on the job. He was fully aware that two model A counters went with the first system and two model B counters went with the second system. It was inconceivable that they could have been mixed up.	STATINTL
STATINTL STATINTL	has your correct mailing address. He will send data regarding their cost overrun on this job. They haven't been paid yet and their first invoice	
STATINTL	is over 60 days old and is in their overdue accounts. has no telephone contact for their contracting officer. He will resubmit the invoice and hope for some action.	
STATINTL	still expects to get the proposal for the 4-axis counter mailed to by Friday April 10. He was happy to hear that it would be acceptable to package the counters as complete units. This is a more standard design for them. It cuts down inter-	STATINTL
	connecting cabling and speeds up assemble and check out. The enclosed Kerox copy of the present control panel is marked to show what will be on the control panel and what will be on the counter. All fout counters will be identical.	STATINTL
	COUNTELS WILL DE IGENTICAL.	

Approved For Release 2007/07/25 : CIA-RDP78B04747A001000060034-4