

INSTALLATION ENGINEERING*Serial # 88007*  
*delivered + installed*  
*11/3-11/5 1964*  
*in DIA area - 5th floor*  
*RAG*

## I. INSTRUMENT

STATINTL

A. Name 880 ComparatorB. Manufacturer C. Contract Number 

## II. PHYSICAL FEATURES

A. Number of Component Parts See Note #1

B. Dimensions of the Largest Component Part:

Length 5 Ft. 2-1/2 In. Height 2 Ft. 4-1/4 In.Width 3 Ft. 9-5/8 In.C. Weight of Largest Component Part 350 lbs.D. Total Weight of Instrument 1100-1200 lbs.

E. Overall Dimensions Assembled:

Length 5 Ft. 2-1/2 In. Height 4 Ft. 5-3/4 In.Width 4 Ft. 3/8 In.

F. Type of Base of Mount:

(Inst. to Console)

Flat Three Point Suspension X Four Point Suspension X (on floor)G. Does Instrument have built-in mobility? NOH. Is the instrument particularly sensitive to vibration? YES

STATINTL

I. Are any special or unusual tools or fixtures necessary or advisable for the installation or maintenance of this equipment? Engineers will accomplish the installation of this equipment. The use of the Universal Gantry (dwg 880-52-12) will be necessary for installation of this equipment and will be brought for the installation.

## III. UTILITIES

A. Electrical:

Voltage 115 Volts + 5 VoltsCurrent 15 Amps-Instrument isFrequency 60 cps fused for 6-1/4 amps.Nr. of phases 1Nr. of wires 2

Power required by equipment

500 WattsWattsType of outlet required: Two Prong Two Prong, Three Prong XTwist Lock Permanent Installation

Should the equipment be shielded, either from external electro-magnetic signals, or to prevent interference with other equipment?

NO

DECLASS REVIEW by NIMA/DOD

## B. Air Conditioning:

Room temperature See Note #2 Humidity 45% Relative Humidity  
 Output of Instrument See Note #3 BTU/Hr.

If air must be filtered, what is maximum permissible particle size  
 in microns? 5-10 each What particle count? \_\_\_\_\_  
 particles per cubic foot. Depends on cleaning routines.

Direct connection to instrument? Yes \_\_\_\_\_ No X

If yes to above, what is the desired air temperature to instrument? \_\_\_\_\_

Should discharged air be ducted separately? \_\_\_\_\_ NO

Is discharged air noxious? \_\_\_\_\_ NO toxic? \_\_\_\_\_ NO

Connector size to instrument \_\_\_\_\_ NA

## C. Plumbing:

Is water required for the instrument? Yes \_\_\_\_\_ No X

Water pressure \_\_\_\_\_ Flow in GPM \_\_\_\_\_

Type of water desired:

Tap	<u>OF</u>	+	<u>OF</u>	
Tempered	<u>OF</u>	+	<u>OF</u>	
Deionized	<u>OF</u>	+	<u>OF</u>	
Filtered	<u>OF</u>	+	<u>OF</u>	

Particle size and count per unit volume.

Type of pipe required:

Galvanized	Copper
Stainless Steel	Plastic

Is floor drain required? Yes \_\_\_\_\_ No \_\_\_\_\_

Diameter of drain	Galvanized drain
Plastic drain	Glass drain

## D. Compressed Air:

Diameter of connectors \_\_\_\_\_ Type of connectors \_\_\_\_\_

PSI \_\_\_\_\_ Water free? \_\_\_\_\_

CFM \_\_\_\_\_ Oil free? \_\_\_\_\_

## E. Vacuum:

Is vacuum required? Yes \_\_\_\_\_ No X

Vacuum required \_\_\_\_\_ PSIA or \_\_\_\_\_ (inches) (milli-  
 meters) of Hg

Displacement \_\_\_\_\_ CFM \_\_\_\_\_

## IV. REMARKS


In the event additional space is required for environmental conditions  
 or utilities not mentioned above, use the reverse side of this form.

See Note #1

N O T E S

1. A film stage (30" dia) is removable from comparator. The power supply for the comparator is stored within the console.  
  
( Drawings are enclosed to furnish information, which will assist you. 880 Comparator floor plan is dwg. no. 880-52-10. Universal Gantry is dwg. no. 880-52-12 880 on skid (front view) is dwg. no. 880-52-11, 1 of 2 880 on skid (side view) is dwg. no. 880-52-11, 2 of 2.)
2. Calibrated at 68° F. May be operated at 70° F. to 72° F. Must be stable.
3. 850 expected -- could be as high as 1700, if it is found necessary ~~to~~ use a mercury light source.

Approved For Release 2002/06/17 : CIA-RDP78B04747A002100040001-4



Approved For Release 2002/06/17 : CIA-RDP78B04747A002100040001-4

STATINTL