

CONFIDENTIAL

77729-4

NPIC/P&DS/D/ [REDACTED]
23 June 1966

25X1A

MEMORANDUM FOR THE RECORD

SUBJECT: Pre-delivery inspection of [REDACTED] Viewer


25X1

1. The undersigned, with [REDACTED], inspected the subject instrument on 20-21 June 1966 with the following results:

25X1

a. Defficiencies and Status:

- (1) Intermittant Loss of X and Y Scanning: Apparently corrected after first morning by vacuuming/cleaning dust from Control Console; however, they will disassemble certain switches and clean electrical contacts.
- (2) MM, Counters Malfunctioned:
 - (a) Left X = Plus(+) count only - corrected
 - (b) Right X = Counts backwards - corrected
 - (c) Right Y = Counts backwards - corrected
 - (d) Right Y = Minus(-) count only - corrected
- (3) Obstruction in Interpupillary Adjustment Below 62mm Setting: Will be corrected prior to delivery.
- (4) Excessive Off-Center Condition of Both Reticle Dots: Corrected the left dot, will correct the right at installation.
- (5) Excessive Off-Center Condition of Two Lowest Power Objectives on Both Sides: Intended to correct the left side as proof of capability, but ran out of time. Both will be properly adjusted at installation to match previous instruments.
- (6) Vacuum Hold-down Time Delay not in Operation: Did not prevent film pull-down, but it will be set up before delivery.
- (7) Y-Motion Translation Did Not Reach Edges of 9.5" Film: Front was corrected and both will be at installation by re-setting limit switches.

DECLASS REVIEW by NIMA/DOD**CONFIDENTIAL**

CONFIDENTIAL

2. Although system resolution missed requirements at several test points (see attached notes), never by more than one target element, which can be accounted for by individual visual characteristics.

3. Although there is no accuracy specification for Navy measurement system, the encoders providing 2.5-micron increments were checked while connected with the [REDACTED] X-Y Counters. Repeatability was invariably to the same reading and never more than one increment off. As discussed with [REDACTED] will install an external connection for the Navy readout system with no charge, if it does not delay delivery; otherwise this will be Navy responsibility. *

25X1A

25X1A

25X1A

4. [REDACTED] requested a written directive to deliver Serial 103 to [REDACTED] for their records - this is being prepared now.

25X1A

5. Since all deficiencies noted are corrected or planned for correction at installation, permission for delivery (now scheduled during first week of July) was given by the undersigned.

25X1A

ADDENDUM:

25X1A

The [REDACTED] Versatile Stereoscope being shipped from [REDACTED] for use on Project 99726-5 had not arrived and could not be checked for resolution, etc. [REDACTED] and determined it "was shipped on 16 June 1966."

25X1A

25X1A

25X1A

Distribution:

Orig - Project File (99729-4)
2 - DB/ISS Chronos

pnf

25X1A

* This offer made by [REDACTED] estimated cost to them of [REDACTED] would be absorbed if parts can be obtained in one week. - AM.

25X1A

CONFIDENTIAL

ILLEGIB

Approved For Release 2002/01/02 : CIA-RDP78B04747A002100090038-9

Approved For Release 2002/01/02 : CIA-RDP78B04747A002100090038-9

BEST COPY

AVAILABLE


ILLUMINATION

General:

ON-OFF switch OK
Dimming control OK
Light levels OK

High Intensity:

Left Right OK
Dimming OK
Light level OK



COUNTERS

Operation OK
Zero Set-Reset OK
Proper count for movement - measure

X + count only OK
R/Y counts backward OK
- count only OK
X counts backward OK

FILM CONTROLS

Looping check switch position OK
Return - Manual withdraw and lock OK
Loop forming left-right OK
Film holddown OK

Time.

(Fast) (Film dry, cracking not representative)

OPTICAL TRAIN CHECKOUT

Check control of eyepiece assembly for function and operation.

| | | |
|---|---------------------------|-----------------|
| Eyestations | Normal <u>OK</u> | |
| | Reversed <u>OK</u> | |
| Image Enhancer switch operation ON - OFF | <u>OK</u> | |
| Channel Selector | Stereo <u>OK</u> | |
| | Superimpose <u>OK</u> | |
| Left Image Selector | Off <u>OK</u> | |
| | Normal <u>OK</u> | |
| | Reversion <u>OK</u> | |
| Right Image Selector | Off <u>OK</u> | |
| | Normal <u>OK</u> | |
| | Reversion <u>OK</u> | |
| Image Rotation Dials 0° to 360° | Operation <u>OK - (L)</u> | <u>OK - (R)</u> |
| | Stops <u>OK - (L)</u> | <u>OK - (R)</u> |

0° Set Up Check

Eyepiece optics in superimposed mode normal image selector X straight edge set up on platen X axis both channels within .001° in 6 inches (use carriage travel and dot to run out straight edge). In turn dial normal ^{to} reversion mode ^{view} an image of offset straight edges should remain parallel within 1 ^{for} any combinations of normal or reversion modes in either channel.

OK perhaps 1/2 of 1°

Interpupillary Adjustment
52mm to 73mm

check clearances at (52) before delivery

With Image Enhancer off, focus eyepiece to obtain sharpest image of fiber bundle pattern on end of fiber cable for both eyepieces. Turn Image Enhancer on. Check fine phasing control for center position with sharpest image of Air Force Resolution Chart at midposition of fine phasing control rotation.

Introduce d Approved For Release 2002/01/02 : CIA-RDP78B04747A002100090038-9

approximately 4 arc minutes).

| | LEFT | RIGHT |
|------------------------------|-------------------|-----------|
| 1-4 arc minutes required | Maximum <u>OK</u> | <u>OK</u> |
| at all system magnifications | Minimum <u>OK</u> | <u>OK</u> |

DOT CENTERING CHECK

Turn on Image Enhancer. Set up 4 arc minute dia. dot (1 multifiber) and cross hair reticles at field stops. Is dot on center? Estimate center error in the following modes with center reticles at field stops. Maximum allowable error is to be 4 arc minutes with any combination.

| | | <u>ERROR (ARC MINUTES)</u> | |
|--|-------|----------------------------|-----------------|
| | | <u>Normal</u> | <u>Reversed</u> |
| | | <u>Eye Sta.</u> | <u>Eye Sta.</u> |
| Run zoom magnification through range | Left | <u>OK</u> ✓ | <u>OK</u> ✓ |
| | Right | _____ | _____ |
| Rotate Image | Left | <u>OK</u> ✓ | <u>OK</u> ✓ |
| | Right | _____ | _____ |
| With image selectors Normal to Reversal, rotate image in four 90° steps between trial for test. | Left | _____ ✓ | _____ ✓ |
| | Right | _____ | _____ |
| With channel selector Stereo to Superimpose, judge center distance on dots, in Normal to Reversion, in rotation and at zoom extremes, each channel, 4 arc minutes error maximum any combination. | Left | _____ | _____ |
| | Right | _____ | _____ |
| Check intensity control of reticle | | <u>OK</u> | |
| Can dot be seen relative to open gate high intensity maximum setting? | Left | <u>OK</u> | <u>OK</u> |
| | Right | <u>OK</u> | <u>OK</u> |

STATINTL

AT

STATINTL

AT

Check centering of each objective lens by indexing turret. Use highest magnification objective lens for centering. ± 2 minutes maximum error for other lenses (1mm width cross hair reticle set up in field stop).

| lens | ERROR (ARC MINUTES) | |
|----------|---------------------|-------|
| | Left | Right |
| 1.6-6.8X | Re-do | Re-do |
| 29X-12X | " X | " X |
| 101-43X | ? | OK |
| 30X-128X | OK | OK |

Check zoom control for each magnification. ? —

Image to remain on center and in focus throughout full range of zoom without changing objective focus. See resolution optical system below. OK

Zoom shall not coast after power cut off. OK

Zoom shall be capable of manual control. OK

Zoom dials properly oriented for correct indication of zoom limits. OK

Check system magnification at low and high ends of each range. —

| OBJECTIVE LENS RANGE | | L E F T | | R I G H T | |
|----------------------|------|---------|------|-----------|------|
| Low | High | Low | High | Low | High |
| 1.6 | 6.8X | | | | |
| 2.9 | 12X | | | | |
| 10.1 | 43X | | | | |
| 30 | 128X | | | | |

Overlap of magnifications for each range

LEFT

RIGHT

Independent focus control for each objective

OKResolution of optical system using Air Force Resolution ChartsFocus objective at high end only. Do not refocus at low end

| OBJECTIVE LENS RANGE | | L E F T | | | | R I G H T | | | |
|----------------------|------|---------|----------|------|----------|-----------|----------|------|----------|
| Low | High | Low | Req. | High | Req. | Low | Req. | High | Req. |
| 1.6 | 6.8X | 14.2 | 13(3/5) | 57 | 54(5/6) | 16 | 13(3/5) | 57 | 54(5/6) |
| 2.9 | 12X | 22.6 | 24(4/5) | 101 | 93(6/4) | 28.5 | 24(4/5) | 101 | 93(6/4) |
| 10.1 | 43X | 114 | 80(2/5) | 287 | 300(0/5) | 114 | 80(1/5) | 322 | 300(0/5) |
| 30 | 128X | 256 | 224(0/2) | 574 | 640(1/5) | 287 | 224(0/2) | 574 | 640(1/5) |

STATINTL

Std. A.F.
Target200X
Reduced
A. F.
TargetEye station capable of adjustment of ± 3 inches in vertical and horizontal planes with lock. OKEye station capable of rotation of 30 degrees about "X" axis with lock. OK

STATINTL

US AIR FORCE RESOLUTION TARGET

Lines Per Millimeter

| Group No. | <u>-2</u> | <u>-1</u> | <u>0</u> | <u>+1</u> | <u>+2</u> | <u>+3</u> | <u>+4</u> | <u>+5</u> | <u>+6</u> | <u>+7</u> |
|--------------|-----------|-----------|----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| 1 | .250 | .500 | 1.00 | 2.00 | 4.00 | 8.00 | 16.0 | 32.0 | 64.0 | 128 |
| 2 | | | 1.12 | 2.24 | 4.49 | 8.98 | 18.0 | 36.0 | 71.8 | 144 |
| 3 | | | 1.26 | 2.52 | 5.04 | 10.1 | 20.1 | 40.3 | 80.6 | 161 |
| 4 | | | 1.41 | 2.83 | 5.65 | 11.3 | 22.6 | 45.2 | 90.4 | 181 |
| 5 | | | 1.58 | 3.17 | 6.34 | 12.7 | 25.4 | 50.7 | 101.4 | 203 |
| 6 | | | 1.78 | 3.56 | 7.11 | 14.2 | 28.5 | 56.9 | 113.8 | 228 |

Multiply lines/mm value given in above table by magnification ratio of system to obtain true value of resolution.

CHART OF RESOLVING POWER VALUES WHEN ORIGINAL TARGET, U.S.A.F. 1951
IS OPTICALLY REDUCED 200 TIMES

| <u>Group</u> <u>No.</u> | <u>Target</u> <u>No.</u> | <u>Resolving</u> <u>Power</u> <u>(Lines/mm)</u> |
|----------------------------|-----------------------------|---|
| -2 | 1 | 50.0 |
| | 2 | 56.2 |
| | 3 | 63.0 |
| | 4 | 70.6 |
| | 5 | 79.2 |
| | 6 | 89.0 |
| ----- | | |
| -1 | 1 | 100 |
| | 2 | 112 |
| | 3 | 126 |
| | 4 | 141 |
| | 5 | 158 |
| | 6 | 178 |
| ----- | | |
| 0 | 1 | 200 |
| | 2 | 224 |
| | 3 | 256 |
| | 4 | 282 |
| | 5 | 318 |
| | 6 | 356 |
| ----- | | |
| 1 | 1 | 400 |
| | 2 | 450 |
| | 3 | 504 |
| | 4 | 566 |
| | 5 | 636 |
| | 6 | 712 |

ILLUMINATION CHECKS

STATINTL

General illumination levels (ft.-lamberts) measured at film plane

at [REDACTED]

adequate

| | | |
|-------|-------|-------|
| | Low | High |
| Left | _____ | _____ |
| Right | _____ | _____ |

High Intensity illumination (maximum brightness) measured at film plane.

| | | |
|-------------------|-------|-------|
| | Left | Right |
| Color Temperature | _____ | _____ |

High Intensity illumination level (foot-lamberts) measured at eyelens

Left _____ Right _____

Color temperature at 50% level measured at film plane

Left _____ Right _____

Temperature above ambient for film with average density of

STATINTL

2 left in high intensity light path for 30 minutes. Use 30-128X range at maximum brightness setting and with new lamps in light source

[REDACTED]

| | | |
|-------|-------|-------------------------|
| Left | _____ | degrees F above ambient |
| Right | _____ | |

FILM HOLDDOWN AND TRANSPORT

Vacuum pull down time _____ 5" 9 1/2"
 Adequate STATINTL Left _____
 Right _____
 Measure at [REDACTED] Across both formats _____
 Torque required to operate film transport _____ ?

Two independent systems of film spooling. YES

Looping capability single film _____ 18-19 ft 17' ship-to-ops

Loop holding capability. Advance film with fixed loop. OK

| | <u>LEFT</u> | <u>RIGHT</u> |
|---------------------------|----------------|--------------|
| Operation of film brakes | Inboard _____ | _____ |
| after high speed film ad- | Outboard _____ | _____ |
| vance with fully loaded | | |
| 500 ft. spools | | |

OK check at [REDACTED] again STATINTL

Operation of looping mechanisms to thread film _____ OK

~~Failure w/ clutches in 1st disengage all the time~~
~~Repair before delivery~~