

0495
02097

November 21, 1967

25X1

[Redacted]
Post Office Box 6788
Fort Davis Station
Washington, D. C. 20020

25X1
25X1

Attention: [Redacted]

Subject: [Redacted]

Gentlemen:

Enclosed is one copy of our revised Acceptance Test Procedure for the subject contract. This revision includes several additional testing procedures requested by your technical representative.

Under separate cover one copy is also being sent directly to your technical representative.

Very truly yours,

25X1

[Redacted]
Enc.

cc: Ed D.

Program Administrator
Photogrammetric and Military
Systems

Declass Review by NGA.

GROUP 1
Excluded from automatic
downgrading and
declassification


ACCEPTANCE TEST PROCEDURE

For

ANAMORPHIC ATTACHMENT

For

High Power Stereoviewer




25X1

Test performed by _____ DATE _____

DATE _____

Anamorphic Attachment Accepted _____ DATE _____



25X1


Revised 11/7/67

Acceptance Test Procedure for Anamorphic Attachment

The tests will be performed using the standard High Power Stereoviewer equipped with the 3X, 6X and 10X objectives, the 1.3X objective and the 6X and 10X eyepieces except as noted.

1. Resolution

Resolution will be measured axially and at four places at the edge of the field as illustrated in the sketch of the field.



The resolution values of the HPSV without the Anamorphic Attachment will be considered as the reference values. The resolution read with the Anamorphic Attachment in place will be compared with the reference values. The resolution values of the HPSV with Anamorphic Attachment should be at least 90% of the resolution values of the HPSV. A high contrast, black bars on clear background, target will be used.

		HPSV Resolution at Field Position					HPSV With Anamorphic Attachment					Accept	Reject
Objectives	10X Eyepiece Zoom Setting	A	L	R	T	B	A	L	R	T	B		
1.3X	1X	—	—	—	—	—	—	—	—	—	—	—	—
1.3X	2X	—	—	—	—	—	—	—	—	—	—	—	—
3X	1X	—	—	—	—	—	—	—	—	—	—	—	—
3X	2X	—	—	—	—	—	—	—	—	—	—	—	—
6X	1X	—	—	—	—	—	—	—	—	—	—	—	—

-2-

6X	2X	—	—	—	—	—	—	—	—	—	—	—	—
10X	1X	—	—	—	—	—	—	—	—	—	—	—	—
10X	2X	—	—	—	—	—	—	—	—	—	—	—	—

Comments:

		HPSV Resolution at Field Position					HPSV With Anamorphic Attachement					Accept	Reject
6X Eyepiece Objectives	Zoom Setting	A	L	R	T	B	A	L	R	T	B		
1.3X	1X	—	—	—	—	—	—	—	—	—	—	—	—
1.3X	2X	—	—	—	—	—	—	—	—	—	—	—	—
3X	1X	—	—	—	—	—	—	—	—	—	—	—	—
3X	2X	—	—	—	—	—	—	—	—	—	—	—	—
6X	1X	—	—	—	—	—	—	—	—	—	—	—	—
6X	2X	—	—	—	—	—	—	—	—	—	—	—	—
10X	1X	—	—	—	—	—	—	—	—	—	—	—	—
10X	2X	—	—	—	—	—	—	—	—	—	—	—	—

Comments:

-3-

2. Field Size

A scale will be placed in the object plane and the field size will be measured. The Anamorphic Attachment shall not cause more than a 5% loss of field when compared with the standard HPSV.

		HPSV	HPSV With Anamorphic Attachment		
10X Eyepiece Objectives	Zoom Setting	Field Size in mm		Accept	Reject
1.3X	1X	_____	_____	_____	_____
1.3X	2X	_____	_____	_____	_____
3X	1X	_____	_____	_____	_____
3X	2X	_____	_____	_____	_____
6X	1X	_____	_____	_____	_____
6X	2X	_____	_____	_____	_____
10X	1X	_____	_____	_____	_____
10X	2X	_____	_____	_____	_____

Comments:

		HPSV	HPSV With Anamorphic Attachment		
6X Eyepiece					
Objectives	Zoom Setting	Field Size in mm		Accept	Reject
1.3X	1X	_____	_____	_____	_____
1.3X	2X	_____	_____	_____	_____
3X	1X	_____	_____	_____	_____
3X	2X	_____	_____	_____	_____
6X	1X	_____	_____	_____	_____
6X	2X	_____	_____	_____	_____
10X	1X	_____	_____	_____	_____

10X Approved For Release 2004/11/30 : CIA-RDP78B04770A000700010043-8
Comments:

-4-

3. Anamorphic Magnification

25X1 In this test a ☐ 10X wide field eyepiece will be used instead of the
 25X1 ☐ eyepiece. Its purpose is to accept a scale which will be used
 for measuring the lengths of perpendicular meridians. A suitable scale
 or grid will be used in the object plane. The ratio of the lengths of
 perpendicular meridians is a measure of the Anamorphic Magnification.

The Anamorphic Magnification range shall be from 1.0 to 2.2X.

HPSV WITH ANAMORPHIC ATTACHMENT

		Calculated Anamorphic Magnification (Ratio of Perpendicular Meridians)	Accept	Reject
Anamorphic Scale Setting				
3X obj.	1.0			
	1.2			
1X Zoom Setting	1.4			
	1.6			
	1.8			
	2.0			
	2.2			

Comments:

-5-

4. Eye Point Extension and Eye Relief

The difference in length between the standard HPSV eyepoint and the eyepoint of the HPSV with Anamorphic Attachment will be calculated.

Both measurements will be made relative to a fixed point on the HPSV.

		Accept	Reject
Distance with Anamorphic Attachment	_____	_____	_____
Distance with Standard HPSV	_____	_____	_____
Difference - Eyepoint Extension	_____	_____	_____

The eyepoint extension shall be no more than 3 inches.

The eye relief shall be measured from the exit pupil to the eyepiece.

	Standard HPSV	HPSV with Anamorphic Attachment	Accept	Reject
Eye Relief	_____	_____	_____	_____

The Interpupillary separation shall be measured with and without the Anamorphic Attachments in place.

	Standard HPSV	HPSV with Anamorphic Attachment	Accept	Reject
IPD	_____	_____	_____	_____

Comments:

-6-

5. Interchangeability

The time required to remove the Anamorphic Attachment shall be less than five minutes, without the use of special tools.

Time Required for Removal of the Anamorphic Attachment

Accept Reject

Minutes

Comments:

6. Anamorphic Axis Orientation

Verification will be made that the direction of anamorphic magnification shall be rotatable through 360°.

Accept Reject

Comments:

7. Percent Transmission

The transmission of the Anamorphic Attachment shall be determined.

A small diameter collimated beam of light will be transmitted through

the Anamorphic Attachment equipped with the 10X wide field

25X

compensating eyepiece. The light energy will be measured and will be

compared to the light energy passing through the 10X eyepiece.

25X

The ratio of the two values obtained will be a measure of the light

-7-

transmission of the Anamorphic Attachment.

		Light	Energy	
		1X	2.2X	
(1)	Anamorphic Attachment with 10X			25X
(2)	10X			

$$\% \text{ Transmission} = \frac{(1)}{(2)} \times 100 =$$