

AL-48-802429-/

21 November 1968

Dear Doctor:

We are enclosing herewith five (5) copies of the following report (classified SECRET):

Contract

Monthly Report - 1 October 1968
through 31 October 1968.



R. R. W.

RRW:sjm

Copy #1: WB w/encs. (AL-48-700507-1 thru 5)
2: DW w/enc. (AL-48-700507-6)

Declass Review by NGA.


SECRET

This document contains
6 pages.

AL-48-700507- 001

Copy 1 of 21 copies

CONTRACT



MONTHLY REPORT

25X1

1 October through 31 October 1968

31 October 1968

SECRET

GROUP 1
EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

SECRET

Contract
Monthly Report

25X1

PAR 247

31 Oct 68

SUBJECT: Base Spare Parts Kit

TASK/PROBLEM

1. Provide one base spare parts kit for two Precision Enlargers, PAR 243A.

25X1

DISCUSSION

2. The red filters were received and the fluid injection pumps were retrofitted to substitute stainless steel for teflon material.

3. The kit is now being packed, and final crating for shipment to the customer is scheduled to begin by 25 November 1968

PLANNED ACTIVITY

4. Crate and ship kit to customer prior to 15 December 1968 (task completion date).

-1-

SECRET

GROUP 1
EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

SECRET

Contract

Monthly Report

25X1

PAR 248

31 Oct 68

SUBJECT: BPE High-Magnification Lens Set

TASK/PROBLEM

1. Provide one high-magnification lens set (PAR 245) to increase the magnification range of a Precision Enlarger (PAR 243A) at the customer's facility.

DISCUSSION

2. Calibration and testing were completed, and the set is now being packed. Crating for final shipment is scheduled to be completed by 15 November 1968.

PLANNED ACTIVITY

3. Pending receipt of shipping instructions, ship the lens set on 15 November 1968.

SECRET

GROUP 1
EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

SECRETContract
Monthly Report

25X1

PAR 249

31 Oct 68

25X1
SUBJECT: Precision Enlarger Prototype (BPE) Operational
Improvements and Maintenance

TASK/PROBLEM

25X1
1. Provide photographic enlarger maintenance at the customer's facility for one Precision Enlarger (BPE) and three 10-20-40X Enlargers.

DISCUSSION

2. Contractor personnel visited the customer's facility during the week of 28 October 1968. The purpose of the visit was to perform the one-month preventive maintenance check on the BPE, and the two-month preventive maintenance check on the four 10-20-40X Enlargers. (See check list indicating the work performed.)

3. During the BPE maintenance check referred to above, the non-steering rollers (P/N 1-023-E-405 and -406) were found to be defective. Replacement rollers were sent by the contractor, installed, and subsequent tracking tests indicated that performance was satisfactory.

4. During the check on the four 10-20-40X Enlargers, the customer described a fluid bubble problem observed after customer personnel had ground the film plane condenser lenses (P/N AL-1160-250) to remove scratches. The customer has requested a price quotation for four of these lenses, as replacements. It was also noted during this check that the gear (P/N AL-1160-171) on the Y-coordinate counter of Enlarger S/N 123 was not pinned to the counter shaft.

PLANNED ACTIVITY

5. During the next trip to the customer's facility currently scheduled for 3 December 1968, accomplish the following:

a. Pin the Y-coordinate counter gear to the counter shaft of 10-20-40X Enlarger S/N 123.

b. Perform monthly preventive maintenance on the BPE and the four 10-20-40X Enlargers.

-3-

SECRET**GROUP 1**
EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

SECRET**PREVENTIVE MAINTENANCE SCHEDULE CHECK LIST**

PAR 249

31 Oct 68

25X1

PRECISION ENLARGER

Assigned to: B-213 Date: 10/31/68 Machine Serial No.

25X1

✓	Item	Description
---	------	-------------

Daily Interval

1	Check the four indicator lamps on the sub-control panel.
2.1	Check closed-negative-gate interlock.
2.2	Check interlock that causes vertical transport slow speed.
2.3	Check interlock that disables negative transport after fluid injection.
2.4	Check operation of microswitch that functions when manual-film-movement knob is pushed in.
3.1	Check the indicator lamps for the two attenuator banks of the easel photometer.
3.2	Check the meter scale illuminator lamp of the easel photometer.
3.3	Check the antifatigue lamp in photo-multiplier tube housing.
4	Clean the glass plates of the negative gate.

One-Week Interval

✓ 1	Wipe vacuum clean the enlarger down.
✓ 2	Check, and if necessary, clean the objective lenses and all glass filters.
✓ 3	Wash vacuum clean the front surface of the easel.
✓ 4	Check the fiber optics for broken fibers.

REMARKS:

1. Replaced Lamphouse Platen Assembly 1-023-C-330.
2. Installed Vertical Drive Limit Switches. Checked out OK.
3. Sealed all Lens Barrel Assemblies with R.T.V.
4. BPE needs washer 2-023-A-627 (item 114, Dwg. 1-023-E-002, Negative Transport System).
5. Delivered 25 bulbs for Decitrak Reader (green base).
6. Replaced non-steering rolls, 1-023-E-405 and 406.
7. Adjusted fluid pumps.

-4-

Checked by Date 10/31/68

2/68

25X1

SECRETEXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

25X1

Approved For Release 2005/02/17 : CIA-RDP78B04770A001300010069-3

Approved For Release 2005/02/17 : CIA-RDP78B04770A001300010069-3