

SECRET

This document contains
15 pages.

AL-700511-69- 00/
Copy / of 21 copies

FY-69

QUARTERLY REPORT

No. 3

28 February 1969

(1 December 1968 - 28 February 1969)

Prepared by:

[Redacted Signature Box]

25X

5X1 Approved by:

Declass Review by NGA.

[Redacted Signature Box]

Date: 27 March 1969

SECRET

GROUP 1

EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

SECTION I

INTRODUCTION

SECRET

28 Feb 69

PROGRAM OBJECTIVE

To investigate through studies, tests, and the fabrication and use of engineering breadboard equipment, new methods or devices which will further the state of the art in photographic techniques and practices as it pertains to improved extraction of collected intelligence information from photographic materials.

-1-

SECRET

GROUP 1
EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

SECRET

28 Feb 69

SUMMARY

- 5X1
1. This Contract FY-69 Quarterly Report No. 3 is submitted in lieu of the February 1969 Monthly Report, and covers progress for the months of December 1968, and January and February 1969.
 2. Detailed reports on approved, active PARs are found in Section II of this report.

-2-

SECRET

GROUP 1

EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

SECRET

28 Feb 69

DISCUSSION

3. PAR Status. The table below lists all PARs in numerical order for ready reference, and the title (condensed in some cases) and status of each.

PAR	Title	Status
201	Travel and Liaison	Active
202/ 224	 Precision Enlarger/* 3X - 15X Enlarger	Completed/TWX 6351 dtd 21 Jan 66
203	Rapid Access Printer	Completed 4 Aug 65
204	Contact Chip Printer	Termination Rpt completed 27 Jan 65
205	Precision 4X Enlarger	Termination Rpt completed 27 Jan 65
206	Reversal Processing Study	Completed 21 May 65
207	Contact Printer Study	Completed 6 Apr 66
208	Non-Elec. Image Enhancement	Cancelled
209	Phosphor Viewer	Cancelled
210	Laminated Slides	Completed 4 Sep 64
211	Processing Effects Study	Completed 28 Oct 65
212	Color Acq. System Review	Completed 28 Oct 65
213	Color Reprod. Review	Completed 13 Aug 65
214	Roller Transport Processor (12-Inch)	Closed/TWX 7284 dtd 23 May 66
215	Roller Transport Processor (24-Inch)	Closed/TWX 7284 dtd 23 May 66
216	Laser Photographic Exposure	Completed 12 Feb 65
217	Optimization of Lasers	Completed 9 Nov 65
218	Autofocus Systems	Not to be submitted
219	Opt. vs Contact Pg. 1:1	Not to be submitted
220	Static Elec. Hold-Down	Disapproved

* Formerly called the Briefing Print Enlarger.

SECRET**GROUP 1**

EXCLUDED FROM AUTOMATIC DOWNGRADING

SECRET

28 Feb 69

PAR	Title	Status
221	Lens Bench Manual	Not to be submitted
222	Auto Stereo Registrn System	Completed 3 Mar 65
223	Monochr. Lens System	Disapproved
225	Micro-D Training Program	Terminated
226	Edge Trace Meas., Micro-D	Completed
227	Color Viewer	Disapproved
228	Vectograph Study	Not to be submitted
229	Optical Design Film Viewer	Not to be submitted
230	10X Color Lens	Disapproved
231	10-20-40X Color Lamphouse	Disapproved
232	Automated Edge Trace Device	Disapproved
233	Zoom (6X to 60X) Projection Lens	Terminated/TWX 7878 dtd 26 Jul 66
234	MTF Exposure Device	Disapproved
235	Automation Program Study	Disapproved
236	Film Disposal Rewind Unit	Disapproved
237	Briefing Aids	Completed 25 Jul 65
238	Equipment Installation	Closed/TWX 7284 dtd 23 May 66
239	Administration	Closed
240	Not Assigned	-
241	Not Assigned	-
242A	Color Demonstration Material	Completed 29 Mar 66
243A	 Precision Enlarger*	Completed 22 Sep 67
244	Spare Parts for RT Processors	Completed 21 Nov 67
245	BPE High Magnification Lens Sets	Completed 26 Mar 68
246	RT-12 and RT-24 Operational Improvements	Completed 25 Feb 68

* Formerly called the Briefing Print Enlarger.

-4-

SECRET**GROUP 1**

EXCLUDED FROM AUTOMATIC DOWNGRADING

SECRET

28 Feb 69

<u>PAR</u>	<u>Title</u>	<u>Status</u>
247	Base Spare Parts Kit	Completed 25 Nov 68
248	BPE High-Magnification Lens Set	Completed 15 Nov 68
5X1 249	<input type="checkbox"/> Precision Enlarger Prototype (BPE) Operational Improvements and Maintenance	Active
5X1 250	<input type="checkbox"/> Precision Enlarger Mod II (Prototype)	Disapproved
251	Image Enhancement Studies Using Ring Smear Techniques	Disapproved

SECRET**GROUP 1**EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

SECTION II

PAR PROGRESS

SECRET

25X1

FY-69 Quarterly Report No. 3

PAR 249

28 Feb 69

5X1
SUBJECT: [] Precision Enlarger Prototype (BPE) Operational
Improvements and Maintenance

TASK/PROBLEM

5X1
1. Provide photographic enlarger maintenance at the customer's facility for one [] Precision Enlarger (BPE) and three 10-20-40X Enlargers.

DISCUSSION

2. Contractor personnel visited the customer's facility three times during the report period and performed the following maintenance while there.

a. During the week beginning 9 December 1968 (reported in the December 1969 monthly report): Maintenance checks on four 10-20-40X enlargers and one BPE enlarger. In addition, the 10-20-40X S/N 123 had a slipping gear on the "Y" coordinate counter. The gear was drilled and pinned for more effective operation.

b. During the week beginning 6 January 1969 (reported in the January 1969 monthly report):

(1) The lamp in the "E" condenser on the BPE was changed because the "getter" that is spot welded to one of the wires was broken off inside the bulb.

(2) Two switches were replaced in the Lectra timer.

(3) Defective lights were replaced in the "Y" coordinate readout.

(4) A maintenance check on the BPE enlarger was performed (see check list for 8 January 1969 attached).

SECRET

GROUP 1

EXCLUDED FROM AUTOMATIC DOWNGRADING
AND DECLASSIFICATION

~~SECRET~~

PAR 249

28 Feb 69

c. During the week of 3 February 1969:

(1) The four 10-20-40X enlargers received their regular two-month check in accordance with the prescribed Preventive Maintenance check lists (see attached). No major problems were noted. Two of the enlargers still need static eliminator power unit A-2 replaced as reported previously; however, the customer has not yet procured these parts.

(2) The Precision Enlarger (BPE) was inspected and the monthly Preventive Maintenance was performed on schedule (see check list dated 5 February 1969). The bridge rectifier (CR⁴) that supplies dc voltage to the solenoid of the fluid brushes was replaced to correct the problem reported in January.

d. During the week of 17 February, a call was received from the customer that the gate glass on the "D" lens of the BPE had become uncemented and fallen off. To effectively re-cement the lens it had to be returned to the contractor's facility. Because this type of repair is outside the scope of preventive maintenance, it was decided by agreement with the customer to absorb the cost for repair on the PAR.

PLANNED ACTIVITY

3. Complete repair of the "D" lens, and return it to the customer.
4. Perform monthly preventive maintenance on the BPE during the week beginning 3 March 1969.

SECRET

PREVENTIVE MAINTENANCE SCHEDULE CHECK LIST

☐ PRECISION ENLARGER

Assigned to

✓	Item	Description
---	------	-------------

Daily Interval

1	Check the four indicator lamps on the sub-control panel.
2.1	Check closed-negative-gate interlock.
2.2	Check interlock that causes vertical transport slow speed.
2.3	Check interlock that disables negative transport after fluid injection.
2.4	Check operation of microswitch that functions when manual-film-movement knob is pushed in.
3.1	Check the indicator lamps for the two attenuator banks of the easel photometer.
3.2	Check the meter scale illuminator lamp of the easel photometer.
3.3	Check the antifatigue lamp in photo-multiplier tube housing.
4	Clean the glass plates of the negative gate.

One-Week Interval

1	Vacuum-clean the enlarger.
2	Check, and if necessary, clean the objective lenses and all glass filters.
3	Vacuum-clean the front surface of the easel.
4	Check the fiber optics for broken fibers.

✓	Item	Description
---	------	-------------

One-Month Interval

✓ 1	Wax the steel rails of the lens ramp and of the easel.
✓ 2	Install new air filter in lamphouse.
✓ 3	Clean the nylon brushes of the fluid removal system.
✓ 4	Check all tubing and hoses for cracks and air leakage.
✓ 5	Check and, if necessary, clean the lenses of the condenser lens assemblies.

Six-Month Interval

1.1	Make a photographic check on all six matching sets of objective and condenser lens assemblies.
1.2	Be sure that film is tracking properly in both directions on the negative transport system.
2	Check the timing belts of the film transport system, of the vertical drive system, and of the easel drive assembly for wear.

Checked by: CAP/HR Date 8 Jan 69

REMARKS:

Replaced "F" condenser bulb.

SECRET

GROUP 1

PREVENTIVE MAINTENANCE SCHEDULE CHECK LIST
TWO-MONTH INTERVAL

PRECISION ENLARGER, 10-20-40X

25X1

Assigned To _____

Date: _____

Machine Serial _____

✓	Item	Description	✓	Item	Description
	1	Film Transport		8	Vacuum Pump Assembly
* ✓	1.1	Static Removal Unit	NA	8.1	Hoses and Couplings
** ✓	1.2	Guide Roller Flanges	NA	8.2	Pump
✓	1.3	Air Knives	NA	8.3	Oil Level
✓	1.4	Belts and Pulleys		9	Lamp House Assembly
✓	1.5	Lubricate Bearings	✓	9.1	Housing
	2	Easel and Stencil Assembly	✓	9.2	Filter (Photographic)
NA	2.1	Easel	✓	9.3	Light Leaks
NA	2.2	Air Pressure System	✓	9.4	Lamp House Blower
	3	Illuminator		10	Immersion System
✓	3.1	Glass	*** ✓	10.1	Ejectors
✓	3.2	Lamps	✓	10.2	Hoses and Couplings
✓	4	Negative Gate Interlock	✓	10.3	Blower
✓	5	Lenses	✓	10.4	Fluid Level
✓	6	Stripper Plate	✓	11	Lamp House Control
	7	Air Pressure System	✓	12	Analyzer
	7.1	Air Lines		13	Photo Check
NA	7.2	Compressor Control		13.1	Resolution
NA	7.3	Relief Valve		13.2	Uniformity
	7.4	Regulator	✓	14	General Inspection
NA	7.5	Filter-Compressor			
NA	7.6	Drain Storage Tank			

Initials CAC

REMARKS:

- * Power pack needs replacement.
- ** Flanges froze in 9.5-inch position.
- *** Upper ejector bent; requires replacement.

Form No. MS-103

March 26, 1966

SECRET

GROUP 1
 EXCLUDED FROM AUTOMATIC DOWNGRADING
 AND DECLASSIFICATION

PREVENTIVE MAINTENANCE SCHEDULE CHECK LIST **TWO-MONTH INTERVAL**

PRECISION ENLARGER, 10-20-40X

Assigned To: _____

Date: _____

Machine Serial _____

25X1

✓	Item	Description	✓	Item	Description
	1	Film Transport		8	Vacuum Pump Assembly
* ✓	1.1	Static Removal Unit	NA	3.1	Hoses and Couplings
** ✓	1.2	Guide Roller Flanges	NA	8.2	Pump
✓	1.3	Air Knives	NA	8.3	Oil Level
✓	1.4	Belts and Pulleys		9	Lamp House Assembly
✓	1.5	Lubricate Bearings	✓	9.1	Housing
	2	Easel and Stencil Assembly	✓	9.2	Filter (Photographic)
NA	2.1	Easel	✓	9.3	Light Leaks
NA	2.2	Air Pressure System	✓	9.4	Lamp House Blower
	3	Illuminator		10	Immersion System
✓	3.1	Glass	✓	10.1	Ejectors
✓	3.2	Lamps	✓	10.2	Hoses and Couplings
*** 4		Negative Gate Interlock	✓	10.3	Blower
✓	5	Lenses	✓	10.4	Fluid Level
✓	6	Stripper Plate	✓	11	Lamp House Control
	7	Air Pressure System	✓	12	Analyzer
✓	7.1	Air Lines		13	Photo Check
NA	7.2	Compressor Control		13.1	Resolution
NA	7.3	Relief Valve		13.2	Uniformity
✓	7.4	Regulator		14	General Inspection
NA	7.5	Filter-Compressor			
NA	7.6	Drain Storage Tank			

Initials CAC

REMARKS:

- * Power pack needs replacement.
- ** Flanges froze in the 9.5-inch position.
- *** Cam requires replacement.

Form No. MS-103

March 26, 1966

PREVENTIVE MAINTENANCE SCHEDULE CHECK LIST
TWO-MONTH INTERVAL

PRECISION ENLARGER, 10-20-40X

25X

Assigned To: _____

Date: _____

Machine Serial No _____

✓	Item	Description	✓	Item	Description
	1	Film Transport		8	Vacuum Pump Assembly
✓	1.1	Static Removal Unit	NA	8.1	Hoses and Couplings
✓	1.2	Guide Roller Flanges	NA	8.2	Pump
✓	1.3	Air Knives	NA	8.3	Oil Level
✓	1.4	Belts and Pulleys		9	Lamp House Assembly
✓	1.5	Lubricate Bearings	✓	9.1	Housing
	2	Easel and Stencil Assembly	✓	9.2	Filter (Photographic)
NA	2.1	Easel	✓	9.3	Light Leaks
NA	2.2	Air Pressure System	✓	9.4	Lamp House Blower
	3	Illuminator		10	Immersion System
✓	3.1	Glass	**	10.1	Ejectors
*✓	3.2	Lamps	✓	10.2	Hoses and Couplings
✓	4	Negative Gate Interlock	✓	10.3	Blower
✓	5	Lenses	✓	10.4	Fluid Level
✓	6	Stripper Plate	✓	11	Lamp House Control
	7	Air Pressure System	✓	12	Analyzer
✓	7.1	Air Lines		13	Photo Check
NA	7.2	Compressor Control		13.1	Resolution
NA	7.3	Relief Valve		13.2	Uniformity
✓	7.4	Regulator	✓	14	General Inspection
NA	7.5	Filter-Compressor			
NA	7.6	Drain Storage Tank			

Initials CAC

REMARKS:

- * One lamp needs replacement.
- ** Upper ejector bent; needs replacement.

Form No. MS-103
 March 26, 1966

PREVENTIVE MAINTENANCE SCHEDULE CHECK LIST
TWO-MONTH INTERVAL

PRECISION ENLARGER, 10-20-40X

25X

Assigned To: _____

Date: _____

Machine Serial _____

✓	Item	Description	✓	Item	Description
	1	Film Transport		8	Vacuum Pump Assembly
✓	1.1	Static Removal Unit	NA	8.1	Hoses and Couplings
✓	1.2	Guide Roller Flanges	NA	8.2	Pump
✓	1.3	Air Knives	NA	8.3	Oil Level
✓	1.4	Belts and Pulleys		9	Lamp House Assembly
✓	1.5	Lubricate Bearings	✓	9.1	Housing
	2	Easel and Stencil Assembly	✓	9.2	Filter (Photographic)
NA	2.1	Easel	✓	9.3	Light Leaks
NA	2.2	Air Pressure System	✓	9.4	Lamp House Blower
	3	Illuminator		10	Immersion System
✓	3.1	Glass	✓	10.1	Ejectors
✓*	3.2	Lamps	✓	10.2	Hoses and Couplings
✓	4	Negative Gate Interlock	✓	10.3	Blower
✓	5	Lenses	✓	10.4	Fluid Level
✓	6	Stripper Plate	✓	11	Lamp House Control
	7	Air Pressure System	✓	12	Analyzer
✓	7.1	Air Lines		13	Photo Check
NA	7.2	Compressor Control		13.1	Resolution
NA	7.3	Relief Valve		13.2	Uniformity
✓	7.4	Regulator		14	General Inspection
NA	7.5	Filter-Compressor			
NA	7.6	Drain Storage Tank			

Initials CAC

REMARKS:

* Three lamps need replacement.

Form No. MS-103

March 26, 1966

PREVENTIVE MAINTENANCE SCHEDULE CHECK LIST

PRECISION ENLARGER

Assigned to

✓	Item	Description
---	------	-------------

Daily Interval

✓	1	Check the four indicator lamps on the sub-control panel.
✓	2.1	Check closed-negative-gate interlock.
✓	2.2	Check interlock that causes vertical transport slow speed.
✓	2.3	Check interlock that disables negative transport after fluid injection.
✓	2.4	Check operation of microswitch that functions when manual-film-movement knob is pushed in.
✓	3.1	Check the indicator lamps for the two attenuator banks of the easel photometer.
✓	3.2	Check the meter scale illuminator lamp of the easel photometer.
✓	3.3	Check the antifatigue lamp in photo-multiplier tube housing.
✓	4	Clean the glass plates of the negative gate.

One-Week Interval

	1	Vacuum-clean the enlarger.
	2	Check, and if necessary, clean the objective lenses and all glass filters.
	3	Vacuum-clean the front surface of the easel.
	4	Check the fiber optics for broken fibers.

✓	Item	Description
---	------	-------------

One-Month Interval

✓	1	Wax the steel rails of the lens ramp and of the easel.
✓	2	Install new air filter in lamphouse.
✓	3	Clean the nylon brushes of the fluid removal system.
✓	4	Check all tubing and hoses for cracks and air leakage.
✓	5	Check and, if necessary, clean the lenses of the condenser lens assemblies.

Six-Month Interval

	1.1	Make a photographic check on all six matching sets of objective and condenser lens assemblies.
	1.2	Be sure that film is tracking properly in both directions on the negative transport system.
	2	Check the timing belts of the film transport system, of the vertical drive system, and of the easel drive assembly for wear.

Checked by: CAC Date 5 Feb 69

REMARKS:

Replaced rectifier CR4 in fluid brush circuit; replaced two lamps in "Y" readout; replaced two lamps in "X" readout.

SECRET

GROUP 1
 EXCLUDED FROM AUTOMATIC DOWNGRADING

SECTION III

FISCAL SUMMARY

25X1

Approved For Release 2005/02/17 : CIA-RDP78B04770A001300020018-8

Approved For Release 2005/02/17 : CIA-RDP78B04770A001300020018-8