

Chief, Imagery Analysis Division, CIA				DATE 7 October 1966
TO		INITIALS	DATE	REMARKS
DIR				<p style="text-align: center;">F.</p> <p>Attn: Chief, Development Branch</p> <p style="text-align: right;">25X1</p>
DEP/DIR				
EXEC/DIR				
TECH ADV				
SPECIAL ASST				
ASST FOR P&M				
CH/SS				
ASST FOR OPS				
ASST FOR PA				
ASST FOR P&D	1			
CH/CSD				
CH/IPD				
CH/PD				
CH/PSD				
CH/TID				
CH/CIA/IAD				
CH/DIA/XX-4				
CH/DIA/AP-IP				
CH/SPAD				
LO/CGS/CIA				
LO/NSA				

SECRETIAD/OSS-224/66
7 October 1966

MEMORANDUM FOR: Chief, Imagery Analysis Division, CIA

FROM: Chief, Operations Support Staff, IAD/CIA

SUBJECT: Visit to []

25X1

1. On 23 September 1966, [] and I accompanied [] P&DS, to the [] Our purpose was to evaluate a new Diazo processing unit, designed by [] which they proposed to produce for the Rapid Interpretation Printer/Processors (RIPP) we have on order. As you know, we have experienced continuing problems with the proto-type RIPP; most of which center around failures in the processing unit. Learning from this unfortunate experience, [] redesigned the processor in an attempt to eliminate the causes of failure. Design changes include the following:

25X1

25X1

25X1

25X1

a. Reducing the requirement for high ammonia pressure in the processing chamber. This necessitated providing both input and output slots near the bottom of the processor but eliminated the need for "pressure roller" seals, and the use of a desiccant.

b. Use of a new type regulating valve which maintains the ammonia pressure in the processor at 1-4 lbs.

c. New heat sinks to increase the temperature within the processing chamber.

d. Providing additional "O" rings plus a wide (about 11") neoprene belt to guide the Diazo copies through the processor without jamming.

e. Adding a double timing mechanism to automatically regulate the flow of ammonia into the processor during standby periods, i.e., ammonia may flow for a predetermined interval, say one minute, then be cut off for 30 minutes. This will conserve ammonia and eliminate a constant pressure build-up within the chamber.

f. Adding a warning light to indicate a low water level in the water reservoir plus an automatic ammonia shut-off should the water supply fail to operate.

g. Adding two counters to indicate (1) number of exposures made on the printer and (2) the elapsed "on" time of the processor.

h. Provision for removing the complete processing unit from the table by removing four screws.

SECRET

GROUP 1
Excluded from automatic
downgrading and
declassification

SECRET

IAD/OSS-224/66

i. Modification of the control panel to provide two spaces for storing Diazo materials.

j. Although not on the test model, our units will include an incandescent light source in the print box for convenience in aligning the area to be printed, and an annotation to indicate the proper orientation of a Diazo sheet on the printer.

k. Tests also indicated the need for the addition of "drive" rollers at the input and output slots. These will be added to production units and ~~are to be externally mounted on the processor~~. By removing the drive rollers, the processing unit (less ammonia and water tanks) will fit into one of our steel fly-a-way boxes for possible transport to a field station.

2. During the course of the day, we ran several tests on the RIPP and made densitometer readings on the samples. The D-max (maximum density) ran about 1.76, with adequate tonal range. Samples did indicate two potential problems: (1) the appearance of occasional smudge marks - like those made by an eraser on a pencil, and (2) some "modeling" in the Diazo emulsion. [] intends to determine and eliminate the cause of the smudge marks, and to confer with [] regarding better quality control in their Diazo coating system.

25X1

25X1

3. Over-all the new processor was judged by [] and myself to be much superior to the prototype and on this basis [] instructed [] to proceed with production for our new units. The first of five (5) units is now scheduled for the week of 5 December with the others to follow within one month. When delivering the first unit, [] intends to pick up the prototype and return it to the factory for modifications ~~to~~ the new design.

25X1

25X1

25X1

25X1

4. The attached Polaroid photos show the new processing unit set up on a test bench and indicate both the external and internal configurations.

5. We were able to spend about two (2) hours with [] Vice-President, [] at their High Ridge Road facility. After discussing their current efforts in the R&D field, we made a short tour of their laboratories, but learned nothing of particular significance to the IAD at this time.

25X1

25X1

25X1

Attachment

Six (6) Polaroid Photos

Distribution

Original - Addressee

1 - P&DS/Ch/DB

2 - OSS/IAD

SECRET